



XAPP1158 (v1.0) September 27, 2013

Using VxWorks BSP with Zynq-7000 AP SoC

Authors: Uwe Gertheinrich, Simon George, Kester Aernoudt

Summary

VxWorks from Wind River:

- Is a Real Time Operating system (RTOS).
- Is a platform-based approach with configurable components that relate to different architecture support, network, file system, compiler and development tool chains.
- Supports the Zynq[®]-7000 All Programmable (AP) SoC architecture of multicore processor systems.
- Has support for asymmetric multiprocessing (AMP) and symmetric multiprocessing (SMP).

This application note is intended as a getting started guide for new users of VxWorks on the Zynq-7000 device. The document contains the following primary sections:

- **Introduction:** Explains the important elements of the Zynq-7000 software environment to provide a better understanding of BSP and application generation. This includes the:
 - ROM mechanism
 - Function of the first stage bootloader (FSBL)
 - Wind River bootloader
 - Explanation of the Zynq-7000 processor subsystem boot process
- **Building VxWorks for Zynq-7000 AP SoC, page 5:** Explains native flash (SD Card) and remote Ethernet (FTP) boot source options and the bootloader configurations for both options.
- **Building and Debugging the Application, page 17:** Explains how to create, build and remotely run a custom application with VxWorks on a Zynq-7000 device.

This document assumes familiarity with the Xilinx[®] ISE[®] Design Suite and Zynq-7000 AP SoC design methodology. This document includes a reference system for the Xilinx ZC702 board derived from the *Zynq-7000 AP SOC - Concepts, Tools and Techniques User Guide [Ref 1]*, which provides the details on how to rebuild such a system.

- **Accessing a Peripheral in the Processing System, page 20:** Describes how to access peripheral systems in the Zynq-7000 Processing System (PS).
- **Conclusion, page 25:** Summarizes what this application note describes.
- **Additional Resources, page 25:** Provides additional resource links.

Hardware and Software Requirements

Software Requirements

- Xilinx® ISE® Design Suite: Embedded or System Edition 14.6 or Vivado® Design Suite, 2013.2.
- Wind River Workbench for VxWorks 6.9.3, which includes a Zynq-7000 AP SoC BSP
- Serial Communication utility program (such as Tera Term)

Hardware Requirements

- Xilinx ZC702 Development Board
- Ethernet Cable
- USB UART Cable

Introduction

The Zynq-7000 AP SOC devices takes advantage of the on-chip CPU to facilitate configuration. Initial device configuration of the processing system (PS) and the programmable logic (PL) must take place through the PS when not using JTAG.

Two major blocks control the configuration:

- The first is the BootROM which is a static block of memory that is executed by the multiprocessor core after power-on reset and warm reset.
- The second major block is the device configuration unit which controls JTAG debug access and provides an interface to the AES, HMAC, and PCAP blocks for PL configuration and data decryption.

Both the PS and PL can be configured under PS control either securely or non-securely. Configuration under external host control is also possible using JTAG.

Unlike other Xilinx 7 series devices, Zynq-7000 AP SOC devices do not support initial PL controlled configuration. Configuration on the Zynq-7000 AP SOC devices is a multi-step process. The configuration process involves a minimum of two stages, but generally requires three stages.

The stages are:

- [Stage 0: BootROM, page 3](#): Referred to as the BootROM, this stage controls initial device startup. The BootROM is non-modifiable code executed by the processor after power-on reset and warm reset.
- [Stage 1: First Stage Bootloader, page 4](#): This is generally a first stage boot loader (FSBL), but it can be any user-controlled code. See the *Zynq-7000 AP SOC Software Developers Guide (UG821)* [Ref 1] for details about FSBL.
- [Stage 2: VxWorks Bootloader, page 4](#): This is generally user-configurable software that can act as a second stage boot loader (SSBL). This stage is completely within user control. In the case of this document, it is part of the VxWorks bootloader.

[Figure 1, page 3](#) illustrates a non-secure boot process for typical Linux system. Uboot is an example for higher-level boot loader and can be exchanged by VxWorks bootloader.




Figure 1: Boot Flow

Stage 0: BootROM

The Zynq-7000 AP SoC processor subsystem configuration starts after power-on reset. The ARM® CPU starts executing code from the on-chip BootROM with JTAG disabled. The BootROM contains code for base drivers for NAND, NOR, Quad-SPI, SD, and PCAP. DDR and other peripheral initializations are not performed from the BootROM and must be done in the Stage 1 image, First Stage Bootload (FSBL) or later.

For security, the CPU is always the first device out of reset among all master modules within the PS. When the BootROM is running the JTAG is disabled to ensure security.

The BootROM code is also responsible for loading the FSBL. Zynq-7000 AP SoC architecture supports multi-stage user boot image loading; any further user boot image loading after FSBL is the responsibility of the user. When the BootROM releases control to FSBL, user software assumes full control of entire system. The only way to execute the BootROM again is by performing a reset.

The PS boot source is selected using the mode-pin signals (indicated by a weak pull-up or pull-down applied to specific pins), which are sampled after during power-on reset. The sampled value is stored in the `BOOT_MODE` register.

The BootROM supports encrypted and unencrypted images referred to as secure boot and non-secure boot, respectively. Additionally, the BootROM supports beginning execution of the stage 1 image from OCM after copying the image or executing direct from linear flash (NOR or QSPI) when using the execute-in-place (XIP) feature.

- In secure boot the CPU, running from secure BootROM code, decrypts and authenticates the incoming user PS image, stores it in the OCM RAM, and then branches into that RAM.
- In non-secure boot the CPU, running from BootROM code, disables all secure boot features including the AES engine within the PL before branching to the user image in the OCM RAM or flash, if XIP is used. The Processor System (PS) boot image is limited to 192 KB unless booting with XIP.

Any subsequent boot stages for either the PS or the PL are the responsibility of the user and are under user control. The BootROM code is not accessible to the user.

- Following the stage 1 secure boot, you can proceed with either secure or non-secure subsequent boot stages.

- Following a non-secure first stage boot, only non-secure subsequent stage boots are possible.

For secure boot decryption and authentication, the PS uses the hard-wired AES-256 and SHA-256 modules within the PL. For this reason, the PL must be powered up during any secure boot, even if only the PS is configured. The device encryption key is user-selectable from either the on-chip eFUSE unit or the on-chip block RAM.

The possible boot sources are: NAND, NOR, SD, Quad-SPI, and JTAG. The first four boot sources are used in master boot methods in which the CPU loads the external boot image from nonvolatile memory into the PS.

Stage 1: First Stage Bootloader

The First Stage Bootloader (FSBL) starts after the execution of the BootROM. BootRom loads the FSBL into the OCM, or the FSBL executes in place (XIP) unencrypted from memory mapped flash (NOR or Quad-SPI), contingent upon the BootROM header description.

The FSBL is responsible for:

- Initialization using the PS configuration data provided by Xilinx Platform Studio (XPS) (see "Zynq-7000 PS Configuration" in the *Zynq-7000 AP SOC Software Developers Guide (UG821)* [Ref 2]).
- Programming the PL using a bitstream
- Loading second stage bootloader or bare-metal application code into DDR memory
- Starting execution of the second stage bootloader or bare-metal application

Note: Before handoff to the second stage bootloader or bare-metal application, the FSBL invalidates the instruction cache and disables the cache and MMU, because Linux (and perhaps other operating systems) assume it is disabled upon start.

See the FSBL code provided with SDK for details on how the FSBL initializes the CPU and peripherals used by the FSBL, and how it uses a simple C run time library.

The bitstream for the PL and the second stage bootloader or bare-metal application data, as well as other code and data used by the second stage bootloader, Linux (or other operating system), or bare-metal application are grouped into partitions in the flash image.

Stage 2: VxWorks Bootloader

The VxWorks bootloader application loads a VxWorks image onto a target. Like VxWorks, you can configure the VxWorks bootloader with various facilities; such as a command line interface for dynamically setting boot parameters, a network loader, and a file system loader.

Uniprocessor (UP), symmetric multiprocessor (SMP), and asymmetric multiprocessor (AMP), configurations of VxWorks use the same bootloader.

In a development environment, a bootloader is useful for loading a VxWorks image from a host system, where you can modify and rebuild VxWorks. You can also use a VxWorks bootloader in production systems when the bootloader and operating system are stored on a disk or other media.

Self-booting (standalone) VxWorks images do not require a bootloader. These images are commonly used in production systems (stored in nonvolatile devices).

Usually, the bootloader is programmed in a nonvolatile device (usually flash memory or EEPROM) at an address such that it is the first code run by the processor when the target is powered on or rebooted. The procedure to get the boot loader programmed in a nonvolatile device or written to a disk is dependent on the target, and is described in following section using an SD card image.

The VxWorks product installation includes default bootloader images for each installed BSP. If they do not meet your needs, you can create a custom bootloader.

Building VxWorks for Zynq-7000 AP SoC

Host Environment Configuration

The following steps are one-time only:

1. Install VxWorks Tool chain 6.9.3.1.
 - a. Install Base Tools Package.
 - b. Invoke the **Product Maintenance** GUI.
 - Update the installer.
 - Configure online **Content Update Network** settings.
2. Apply updates based upon your license file, as shown in [Figure 2](#).




Figure 2: Select Products Dialog Box

The Zynq-7000 BSP is a standard part of the 6.9.3.1 install, as shown in [Figure 3](#):




Figure 3: VxWorks BSP: Xilinx Zynq-7000 EPP

3. Because of the asynchronous nature of VxWorks BSPs, verify that you install the latest Xilinx BSP. The link is provided at [\[Ref 4\]](#).
4. Install the BSP patches as described in the BSP download link: VxWorks 6.9.3.1 BSP Driver Source Patch for BSP, The link is provided at [\[Ref 5\]](#).
5. Complete all details of the build steps to apply the patch into the source tree.

Configure and Build a VxWorks BootROM and Kernel Image

The default BSP does not enable support for accessing an SD card. Because you use the SD card to store the VxWorks image, the first step is to modify the BSP configuration.

1. In a text editor, open the `<Install_Dir>/vxworks-6.9/target/config/xlnx -zynq7k/config.h` file, and modify line 197 from:

```
#undef DRV_STORAGE_SDHC/
to
#define DRV_STORAGE_SDHC
#define INCLUDE_DOSFS
#define INCLUDE_DOSFS_MAIN
#define INCLUDE_DOSFS_CHKDSK
#define INCLUDE_DOSFS_FMT
#define INCLUDE_DOSFS_FAT
#define INCLUDE_DOSFS_SHOW
#define INCLUDE_DOSFS_DIR_VFAT
#define INCLUDE_DOSFS_DIR_FIXED
#define INCLUDE_FS_MONITOR
```

```
#define INCLUDE_FS_EVENT_UTIL
#define INCLUDE_ERF
#define INCLUDE_XBD
#define INCLUDE_XBD_BLKDEV
#define INCLUDE_XBD_TRANS
#define INCLUDE_DEVICE_MANAGER
#define INCLUDE_XBD_BLK_DEV
#define INCLUDE_XBD_PART_LIB
#define INCLUDE_DISK_UTIL
```

This enables the SDHC controller, as well as drivers for the FAT file system.

To use the VxWorks BSP with the Wind River Workbench to create a VxWorks Kernel Image, do the following:

2. Start the Wind River Workbench tool and select a workspace.
The Wind River SDK opens.
3. In the main context menu select **File > New > Project**.
The New Project Wizard opens.
4. Under **VxWorks 6.x**, select the **VxWorks Image Project**, as shown in [Figure 4](#).




Figure 4: VxWorks Image Project

The New VxWorks Image Project multipage wizard opens.

5. Enter a project name, for example, **zynq_vxworks_01**, and click **Next**.
6. Select the **xlnx_zynq7k** BSP used for this project as highlighted in [Figure 5](#).




Figure 5: VxWorks Image Project Multipage Wizard

- From the New VxWorks Image Project wizard, select **PROFILE_DEVELOPMENT** (Figure 6).




Figure 6: New VxWorks Image Project: PROFILE_DEVELOPMENT Option

- Click **Finish**.
- Open the Kernel configuration. Change the configuration to include the symbol table in the Kernel image (Figure 7, page 10).




Figure 7: Component Configuration

You can now build the Kernel image.

Building the Kernel Image

1. In the Project Explorer window, mouse over to the Image project, right-click and select **Build Project**. The VxWorks image file is located in the `.\<project_name>\default` directory. Figure 8 shows the Build Project option.




Figure 8: Build Project Option

2. When the project build is complete, start a Wind River VxWorks development shell. Use this shell to build a bootROM binary. The bootROM binary is the VxWorks bootloader (similar to Uboot); it is not within the Zynq-7000 device ROM.
3. Within the shell, type:


```
cd ..\<install_dir>\Wind
River\vxworks-6.9\target\config\xlnx_zynq7k\
make clean make bootROM
```

 The commands generate a file with the name `bootROM`. Rename the file to `bootROM.elf`
4. Create a `boot.bif` and a `zynq_fsbl_0.elf` file, with the following format:


```
ZC702_bif_for_VxWorks:
{
  [bootloader] zynq_fsbl_0.elf
  bootROM.elf
}
```
5. Copy the `bootROM.elf`, `zynq_fsbl_0.elf`, and the `boot.bif` file to the `/bootgen` directory. Alternatively, you can copy the `bootgen.exe` tool to the current installation directory.


```
C:\<install_dir>\Wind
River\vxworks-6.9\target\config\xlnx_zynq7k\
```

6. In the Wind River shell, type:

```
bootgen image boot.bif I BOOT.BIN
```
7. Copy the following files onto an SD card:
 - VxWorks from the ..\<project_name>\default directory
 - BOOT.BIN from the ...<install_dir>\WindRiver\vxworks 6.9\xlnx_zynq7k\ directory.

This creates a system that can boot from an SD card.

The following subsection describes the required steps to boot from an SD card.

Booting From an Secure Digital Card

Use the Secure Digital (SD) card to boot the Zynq-7000 AP SoC Processor System (PS).

1. Connect a power cable, a Xilinx USB download cable, an Ethernet cable, and a USB UART cable to the board.
2. Put the SD Card in the SD card pole of the board. Ensure that the switches for booting from SD Card are in the right position. Ensure that the settings of Jumpers J27 and J28 are the same as shown. Move the DIP-Switches 3 and 4 of SW 16 to the left (this sets the switches to 1) ([Figure 9, page 13](#)).




Figure 9: Image of SD Card and USB Connection

These settings ensure an SD card boot.

3. Open a terminal session, and choose the right COM port () function, and set the **Baud Rate** to **115200**.
4. Switch on the board.
5. Stop the Autoboot process by pressing the keyboard **Return** key.
The VxWorks bootROM prompt opens.
6. Type **C** at the boot prompt, and press **Return** to start the boot configuration.
7. Change the boot device to **fs** and press **Return** until you reach the file name.
8. Change to **/sd0:1/vxWorks** and press **Return** until you reach **other (o)**.
9. If no entry exists, type **gem0**. Press **Return** and the boot prompt opens.
10. Type **@** to proceed the boot process.
11. Type **i** to display all running tasks.

VxWorks boots and presents the output as shown in [Figure 10](#).




Figure 11: Host Ethernet MAC Configuration

4. Start an FTP server. You can use the server delivered with the Wind River tool chain. If you use the Wind River FTP server, select **Security > User/rights**.
5. Click **New User** and type a name; for example, **Zynq** and a password.
6. Type the home directory of the VxWorks image, then click **Done**.
7. Switch on the board.
8. Stop the Autoboot process by pressing **Return**.
The VxWorks bootROM prompt opens.
9. At the boot prompt, type **c** then press **Return** to start the boot configuration.
10. Type **gem0** to change boot device then press **Return** until you reach **File Name**.
11. Type **VxWorks**, then press **Return** until you reach **inet on ethernet (e)**.
12. Change the **inet on ethernet (e)** to IP address **192.168.1.2:0xfffff00**, then press **Return** until you reach **host inet (h)**.
13. Change **host inet (h)** IP address **192.169.1.1**, then press **Return** until you reach **user**.
14. Type the user name you choose for the server then press **Return** until you reach **password (pw)**.
15. Type password you choose for the server, then press **Return** until you reach **other (o)**.
21. If no entry exists, type **gem0**, then press **Return**.
The boot prompt opens.
22. Type **@** to start the boot process.
VxWorks boots from the image using the terminal (Figure 12, page 16).

Building and Debugging the Application

Creating the Hello World Application

As short example, the following instructions describe how to build and download a small "Hello World" application to the remote target after you have set up and are running VxWorks.

The assumptions are:

- You have followed the prior stages of this document.
- VxWorks is executing on the target (with remote debug enabled).
- An Ethernet connection is present between the host and the target.

To create the "Hello World" application:

1. Select **File > New > Project > VxWorks Downloadable Kernel Module Project**, as shown in [Figure 13](#).




Figure 13: New Project Wizard

2. Click **Next** and enter a project name; for example, **hello_world**, ([Figure 14, page 18](#)), then press **Finish**.




Figure 14: New Kernel Module Project

A `hello_world` project opens in the Project Explorer Window.

3. Move the mouse to the Project. Click the right button and select **New > File**.
4. Enter a file name; for example, `hello.c`, and click **Finish**.
5. Enter the following code into the file:


```
#include <stdio.h>
void hello()
{
printf("Hello Wind River\n");
}
```
6. In the Project Explorer window, select **Build Targets** (Figure 15), and click the right mouse button.




Figure 15: Build Target Selection

7. Select **Build Options > Set Active Build Spec > ARMARCH7<gnu | diab>**.
A message opens that asks if you want to set the active build spec to **ARMARCH7<gnu | diab>** (Figure 16).




Figure 16: Build Target Configuration

8. Select **YES**.
9. Build the project. A message opens.
10. Click **Continue**.
11. In the bottom-left corner of the Wind River Workbench, go to **Remote Systems**.
12. In the window, right-click and select **New > Connection**.
13. Select **Wind River VxWorks 6.x Target Server Connection**, and click **Next**.
14. Type the target IP address of **192.168.1.2**, and the path to the kernel image (in this case type: `\. . \<project_name> \default`). Click **Finish**.
15. Right-click the new connection, and click **Connect**.
16. In the Project Explorer window, right-click **Build Targets**, then select **Debug VxWorks Kernel Task**.
14. The Debug Configuration window opens, as shown in Figure 17, page 20.




Figure 17: Debug Configuration Window

17. From **General > Entry**, type **hello** to locate the **hello world** project.
Alternatively, you can use the **Browse** button to find the **hello world** project.

18. Click **Debug**.

The terminal window that is connected to the board issue the following message:

```
>> Break at 0x0144acc: hello +0x4 Task: 0x14cdfc0 (Hello)
```

Note: The message can differ slightly from yours as it depends on your Kernel settings. It just gives you the hint that a task was downloaded and stopped for debug.

19. In the debug window, click the **Run** button.

The terminal window displays: Hello Wind River.

20. Type **i** to see the tasks in the VxWorks task list.
21. Type **repeat 10,hello** to repeat the task 10 times.

Accessing a Peripheral in the Processing System

In the ARM® Cortex™ A9 processor, every peripheral is memory mapped. The address map for the Zynq-7000 AP SoC processor, for example, is listed in the *Zynq-7000 AP SoC Technical Reference Manual (UG585)* [Ref 2].

Modifying the Hello World Application

Modify the "Hello World" application to access the GPIO peripheral. On the ZC702 board, MIO pin 10 is connected to an LED (DS12).

From the Zynq-7000 AP SoC Technical Reference Manual, (UG585) [Ref 6], you see that the base address of the GPIO peripheral is 0XE000A000. To access pin 10 as an output, you must configure this peripheral first:

1. Set the direction to output by writing a 1 to bit 10 of the gpio.DIRM_0 register.
2. Enable the output by writing a 1 to bit 10 of the gpio.OEN_0 register.
3. Write to bit 10 of the gpio.DATA_0 register to control the LED.

The updated source code of the hello world application now looks like the following:

```
#include <stdio.h>
```

```
#include <sys/mman.h>

#define GPIO_BASE 0xE000A000
#define GPIO_DIRM_0 0x00000204
#define GPIO_OEN_0 0x00000208
#define GPIO_DATA_0 0x00000040

int main(void)
{
    printf("Hello World!\n");

    int val = 0xffffffff;
    sysOutLong(GPIO_BASE + GPIO_DIRM_0, 0x00000400);
    sysOutLong(GPIO_BASE + GPIO_OEN_0, 0x00000400);

    while (1) {
        sysOutLong(GPIO_BASE + GPIO_DATA_0, val);
        sleep(1);
        val ^= 0xffffffff;
    }

    return 0;
}
```

4. Save this file, then build and debug this application following steps 9 to 19 of the previous section. The result is that the LED toggles every second.

Accessing a Peripheral in the Programmable Logic

Accessing a peripheral in the Programmable Logic is very similar to accessing a peripheral in the processing system: both master GP AXI interfaces have an address space of 1GB, as can be seen in the Address Map table in the *Zynq-7000 AP SoC Technical Reference Manual* (UG585) [Ref 6]. The differences are:

- You must first program the PL with a BIT file containing the `AXI_GPIO` peripheral.
- You must modify the VxWorks BSP to allow access to the address range that you configured for that peripheral.

The design created for this section contains an `AXI_GPIO` peripheral connected to the `M_AXI_GP0` port of the PS.

The four GPIO pins of the `AXI_GPIO` peripheral are connected to the DS15 to DS18 LEDs on the ZC702 board.




Figure 18: Zynq-7000 Processor System and Peripherals

The Address Editor shows the base address where this peripheral is mapped, as shown in Figure 19.

Cell	Base Name	Offset Address	Range	High Addr
/processing_system7_1				
Data				
/axi_gpio_1	Reg	0x41200000	64K	0x4120FF1

Figure 19: Address Editor

After implementing this design, you generate a new FSBL, and use this FSBL, together with the generated BIT file, to create a new `boot.bin` file to download to the SD card.

- Follow the same steps as you used but use a slightly modified `boot.bif` file, as follows:

```
//ZC702_bif_for_VxWorks:
{
  [bootloader] fsbl.elf
  bitfile.bit
  bootROM.elf
}
```

Where:

- `fsbl.elf` is the new FSBL.
- `bitfile.bit` is the BIT created by the hardware design.

This produces a new `boot.bin` file to boot the ZC702 board.

- To access the peripheral from within a VxWorks kernel module, first modify the BSP. The default configuration of the VxWorks BSP configures the MMU to allow access to a limited set of addresses, listed in the documentation of the BSP.

Memory Maps

The default memory map of this BSP is as bellows:

Start	Size	End	Access to
0x0000_0000	1M	0x000F_FFFF	OCM
0x0010_0000	1019M	0x3FBF_FFFF	DDR3 SDRAM
0x0FC0_0000	4MB	0x0FFF_FFFF	ROM
0xE000_0000	32MB	0xE1FF_FFFF	I/O PERIPHERALS
0xF800_0000	6000B	0xF800_0BFF	SLCR
0xF8F0_0000	16KB	0xF800_0BFF	SCU
0xFC00_0000	16MB	0xFCFF_FFFF	QSPI FLASH
0xFFFF_0000	4KB	0xF800_0BFF	OCM

Figure 20: Memory Map

Adding the Address Range to the MMU Configuration

The `M_AXI_GP` ports are not mapped.

To add the address range to the MMU configuration, modify the VxWorks BSP:

1. Open the VxWorks image project, then browse to the `/xlns_zynq7k` folder.
2. Double-click the `sysLib.c` file to open the file in the Text Editor.




Figure 21: MMU Configuration

3. In the `syslib.c` file, scroll down to line 109, find the `struct` containing the MMU configuration.

For example, on line 225, find the mapping for the GPIO peripheral used in the previous example:

```
{
ZYNQ7K_GPIO_BASE, /* Zynq-7000 gpio */ ZYNQ7K_GPIO_BASE,
PAGE_SIZE,
    MMU_ATTR_VALID_MSK | MMU_ATTR_PROT_MSK |
MMU_ATTR_DEVICE_SHARED_MSK,
MMU_ATTR_VALID | MMU_ATTR_SUP_RWX |
MMU_ATTR_DEVICE_SHARED
},
```

4. Add the mapping for the AXI_GPIO peripheral by adding the following line:

```
{
0x41200000, /* My AXI gpio */
0x41200000, PAGE_SIZE,
    MMU_ATTR_VALID_MSK | MMU_ATTR_PROT_MSK |
MMU_ATTR_DEVICE_SHARED_MSK,
    MMU_ATTR_VALID | MMU_ATTR_SUP_RWX |
MMU_ATTR_DEVICE_SHARED
},
```

5. Save the file, and rebuild the VxWorks project.
6. Use this VxWorks image, and either:
 - Put the image on the SD card to boot from SD, or
 - When fetching the VxWorks image over FTP, boot the board with the updated `boot.bin` file.
7. After booting the ZC702 board with this SD card, the FSBL configures the PL before launching the VxWorks BootROM.

The BootROM then loads the updated VxWorks image.

Updating the Hello World Project

Update the "hello world" project to access the AXI peripheral. The AXI_GPIO peripheral is slightly different from the hardened GPIO peripheral: you need only to set the direction, not enable the output driver.

Change the contents of the file to:

```
#include <stdio.h>
#include <sys/mman.h>
#define AXI_GPIO_BASE 0x41200000
#define AXI_GPIO_TRI ??????????0x04
#define AXI_GPIO_DATA ??????????0x00
int main(void)
{

printf("Hello World!\n");

int val = 0;
sysOutLong(AXI_GPIO_BASE + AXI_GPIO_TRI, 0);

while (1) {
```



```

sysOutLong (AXI_GPIO_BASE + AXI_GPIO_DATA, val);
printf("%d\n", val);
sleep(1);
val++;
if (val == 0x10000) (val = 0;
}
return 0;
}

```

When you rebuild this project, and run it on the ZC702 board, it toggles the LEDs every second.

Conclusion

This application note has provided step-by-step instructions for running the VxWorks 6.9.3.1 BSP on the Zynq-7000 SoC All Programmable device platform, and additionally provided an overview of the boot process for the Zynq-7000 AP SoC platform.

You now know the steps for using VxWorks RTOS on the Zynq-7000 AP SoC platform.

Additional Resources

The following links are to additional resources referenced in this document:

1. *Zynq-7000 AP SOC - Concepts, Tools and Techniques User Guide* ([UG837](#))
2. *Zynq-7000 All Programmable SoC Software Developers Guide* ([UG821](#))
3. *Zynq-7000 AP SoC Technical Reference Manual*, ([UG585](#))
4. Xilinx BSP: gppve_6_9_xlnx_zynq7k_6_9_2:
<https://portal.windriver.com/cgi-bin/windsurf/bsp/infoBSP.cgi?id=12020>
5. VxWorks 6.9.3.1 BSP Driver Source Patch:
<https://support.windriver.com/olsPortal/faces/maintenance/downloadDetails.jspx?contentId=041654>
6. VxWorks 6.9.3.1 USB L2 Cache Source Patch:
<https://support.windriver.com/olsPortal/faces/maintenance/downloadDetails.jspx?contentId=041575>

Revision History

The following table shows the revision history for this document.

Date	Version	Description of Revisions
09/27/2013	1.0	Initial Xilinx release.

Notice of Disclaimer

The information disclosed to you hereunder (the "Materials") is provided solely for the selection and use of Xilinx products. To the maximum extent permitted by applicable law: (1) Materials are made available "AS IS" and with all faults, Xilinx hereby DISCLAIMS ALL WARRANTIES AND CONDITIONS, EXPRESS, IMPLIED, OR STATUTORY, INCLUDING BUT NOT LIMITED TO WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, OR FITNESS FOR ANY PARTICULAR PURPOSE; and (2) Xilinx shall not be liable (whether in contract or tort, including negligence, or under any other theory of liability) for any loss or damage of any kind or nature related to, arising under, or in connection with, the Materials (including your use of the Materials), including for any direct, indirect, special, incidental, or consequential loss or damage (including loss of data, profits, goodwill, or any type of loss or damage suffered as a result of any action brought by a third party) even if such damage or loss was reasonably foreseeable or Xilinx had been advised of the possibility of the same. Xilinx assumes no obligation to correct any errors contained in the Materials or to notify you of updates to the Materials or to product specifications. You may not reproduce, modify, distribute, or publicly display the Materials without prior written consent. Certain products are subject to the terms and conditions of the Limited Warranties which can be viewed at <http://www.xilinx.com/warranty.htm>; IP cores may be subject to warranty and support terms contained in a license issued to you by Xilinx. Xilinx products are not designed or intended to be fail-safe or for use in any application requiring fail-safe performance; you assume sole risk and liability for use of Xilinx products in Critical Applications: <http://www.xilinx.com/warranty.htm#critapps>.