

# **MIPI CSI-2 Transmit Subsystem v1.0**

## ***Product Guide***

**Vivado Design Suite**

**PG260 June 7, 2017**



# Table of Contents

## IP Facts

### Chapter 1: Overview

Sub-Core Details.....	6
Applications .....	7
Unsupported Features.....	7
Licensing and Ordering Information.....	8

### Chapter 2: Product Specification

Standards .....	9
Resource Utilization.....	9
Port Descriptions .....	9
Pixel Encoding .....	13
Register Space .....	15

### Chapter 3: Designing with the Subsystem

General Design Guidelines .....	22
Shared Logic .....	22
I/O Planning .....	24
Clocking.....	26
Resets .....	27
Protocol Description .....	28

### Chapter 4: Design Flow Steps

Customizing and Generating the Subsystem .....	30
Constraining the Subsystem .....	35
Simulation .....	37
Synthesis and Implementation .....	37

### Appendix A: Verification, Compliance, and Interoperability

Hardware Validation .....	38
---------------------------	----

### Appendix B: Debugging

Finding Help on Xilinx.com .....	39
----------------------------------	----

Debug Tools .....	40
Hardware Debug .....	41
Interface Debug .....	41

## Appendix C: Additional Resources and Legal Notices

Xilinx Resources .....	44
References .....	44
Revision History .....	45
Please Read: Important Legal Notices .....	45

# Introduction

The Mobile Industry Processor Interface (MIPI) Camera Serial Interface (CSI-2) TX subsystem implements a CSI-2 transmit interface according to the MIPI CSI-2 standard, v1.1 [Ref 1]. The CSI-2 TX subsystem packs the incoming pixel data to CSI-2 packets with the required pixel to byte conversion, header and footer insertion. Also generates the required frame and line marker packets. These packets are then sent over DPHY interface for transmission.

## Features

- Support for 1 to 4 D-PHY lanes
- Maximum data rate of 1.5 Gb/s
- Multiple data type support (RAW, RGB, YUV, User defined)
- Support for single, dual, quad pixel modes
- Support for 1 to 4 virtual channels
- Low power state (LPS) insertion between the packets
- Ultra low power (ULP) mode generation using register access
- Interrupt generation to indicate subsystem status information
- AXI4-Lite interface for register access to configure different subsystem options
- Configurable Line Start/Line End packet generation
- Configurable selection of D-PHY register interface


IP Facts Table	
Subsystem Specifics	
Supported Device Family <sup>(1)</sup>	UltraScale+™ Families, Zynq® UltraScale+ MPSoC, Zynq®-7000 All Programmable SoC, Virtex®-7, Kintex®-7, Artix®-7
Supported User Interfaces	AXI4-Lite, AXI4-Stream, Native Video
Resources	<a href="#">Performance and Resource Utilization web page</a>
Provided with Subsystem	
Design Files	Encrypted RTL
Example Design	Not Provided
Test Bench	Not Provided
Constraints File	XDC
Simulation Model	Not Provided
Supported S/W Driver <sup>(2)</sup>	Standalone
Tested Design Flows <sup>(3)</sup>	
Design Entry	Vivado® Design Suite
Simulation	For supported simulators, see the <a href="#">Xilinx Design Tools: Release Notes Guide</a> .
Synthesis	Vivado Synthesis
Support	
Provided by Xilinx at the <a href="#">Xilinx Support web page</a>	

### Notes:

1. For a complete list of supported devices, see the Vivado IP catalog.
2. Standalone driver details can be found in the SDK directory (<install\_directory>/SDK/<release>/data/embeddedsw/doc/xilinx\_drivers.htm). Linux OS and driver support information is available from the [Xilinx Wiki page](#).
3. For the supported versions of the tools, see the [Xilinx Design Tools: Release Notes Guide](#).

# Overview

The MIPI CSI-2 TX subsystem allows you to quickly create systems based on the MIPI protocol. It interfaces between image sensors and an image sensor pipe. An internal high speed physical layer design, D-PHY, is provided that allows direct connection to MIPI based receivers. The top level customization parameters select the required hardware blocks needed to build the subsystem. [Figure 1-1](#) shows the subsystem architecture.



*Figure 1-1: Subsystem Architecture*

The subsystem consists of the following sub-cores:

- MIPI D-PHY
- MIPI CSI-2 TX Controller
- AXI Crossbar

# Sub-Core Details

## MIPI D-PHY

The MIPI D-PHY IP core implements a D-PHY TX interface and provides PHY protocol layer support compatible with the CSI-2 TX interface. MIPI I/O bank support & I/O Planner are present only for UltraScale+ devices. For more details, refer *MIPI D-PHY LogiCORE IP Product Guide (PG202)* [Ref 3].

## MIPI CSI-2 TX Controller

CSI provides the mobile industry a standard, robust, scalable, low-power, high-speed, cost-effective interface that supports a wide range of imaging solutions for mobile devices.

MIPI CSI-2 TX Controller receives stream of image data via Native video or AXI4-Stream input interface. The controller adds the synchronization packets and performs the pixel-to-byte conversions for the pixel data. Packed byte data is sent over the D-PHY interface for transmission. AXI4-Lite interface is used to access core registers. The MIPI CSI2-TX Controller supports ECC and CRC generation for header and payload respectively.




Figure 1-2: MIPI CSI-2 TX Controller Core

Features of this core include:

- Multi-lane interoperability that allows more bandwidth than that provided by one lane. Those trying to avoid high clock rates, can expand the data path to multiple lanes and obtain approximately linear increases in peak bus bandwidth
- Short and long packets with all word count values supported and can be used for low level protocol communication

- Error Correction Code (ECC) for error generation in Long and Short packet header. To detect possible errors in transmission, a checksum is calculated over each data packet. The checksum is realized as 16-bit CRC. The generator polynomial is  $x^{16}+x^{12}+x^5+x^0$
- Supports embedded non-image data transmission using the same input Native video or AXI4S interface.
- Supports active lane configuration, programmable native video interface or AXI4 streaming interface, and programmable CRC generation.

## AXI Crossbar

The AXI Crossbar core is used in the subsystem to route AXI4-Lite requests to corresponding sub-cores based on the address. See the *AXI Interconnect LogiCORE IP Product Guide* [Ref 4] for details.

---

## Applications

The Xilinx MIPI CSI-2 TX controller implements camera sensor transmit interface over MIPI D-PHY interface. It can be used to bridge between non-MIPI camera sensors to MIPI based image sensor processors or to map video data captured over other interfaces such as HDMI and DisplayPort™ to a MIPI CSI interface. MIPI is a group of protocols defined by the mobile industry group to standardize all interfaces within mobile platforms such as mobile phones and tablets. However the large volumes and the economies of scale of the mobile industry is forcing other applications to also adopt these standards. As such MIPI-based camera sensors and Image sensor processors are being increasingly used in applications such as driver assistance technologies in automotive applications, video security surveillance cameras, video conferencing and emerging applications such as virtual and augmented reality.

---

## Unsupported Features

- Secondary data types excluding RAW12,RAW14 are not supported.

# Licensing and Ordering Information

## License Checkers

If the IP requires a license key, the key must be verified. The Vivado® design tools have several license checkpoints for gating licensed IP through the flow. If the license check succeeds, the IP can continue generation. Otherwise, generation halts with error. License checkpoints are enforced by the following tools:

- Vivado synthesis
- Vivado implementation
- write\_bitstream (Tcl command)



**IMPORTANT:** *IP license level is ignored at checkpoints. The test confirms a valid license exists. It does not check IP license level.*

## License Type

This Xilinx module is provided under the terms of the [Xilinx Core License Agreement](#). The module is shipped as part of the Vivado® Design Suite. For full access to all core functionalities in simulation and in hardware, you must purchase a license for the core. Contact your [local Xilinx sales representative](#) for information about pricing and availability.

For more information, visit the MIPI CSI-2 TX Subsystem [product web page](#).

Information about other Xilinx LogiCORE IP modules is available at the [Xilinx Intellectual Property](#) page. For information on pricing and availability of other Xilinx LogiCORE IP modules and tools, contact your [local Xilinx sales representative](#).

# Product Specification

---

## Standards

- MIPI Alliance Standard for Camera Serial Interface CSI-2 v1.1 [\[Ref 1\]](#)
  - MIPI Alliance Physical Layer Specifications, D-PHY Specification v1.1 [\[Ref 6\]](#)
  - Processor Interface, AXI4-Lite: see the *Vivado Design Suite: AXI Reference Guide* (UG1037) [\[Ref 7\]](#)
  - Input Pixel Interface: see the *AXI4-Stream Video IP and System Design Guide* (UG934) [\[Ref 2\]](#)
- 

## Resource Utilization

For full details about performance and resource utilization, visit the [Performance and Resource Utilization web page](#).

---

## Port Descriptions

The MIPI CSI-2 TX Subsystem I/O signals are described in [Table 2-1](#).

*Table 2-1: Port Descriptions*

Signal name	Interface	Direction	Description
<b>DPHY Interface (7 Series family) Shared Logic in the Core</b>			
txclkesc_out	PPI	Output	Use to connect the txclkesc pin.
oserdes_clk_out	PPI	Output	Use to connect the OSERDES clock pin. Frequency of the clock is <code>line_rate/2</code>

**Table 2-1: Port Descriptions (Cont'd)**

Signal name	Interface	Direction	Description
txbyteclkhs	PPI	Output	txbyteclkhs frequency for D-PHY TX when the shared logic is inside the core. The frequency of the clock is <code>line_rate/8.0</code> . This clock has 90° phase shift (quadrature alignment) with <code>oserdes_clk_out</code>
system_rst_out	PPI	Output	Active-high system reset Output to be used by the example design level logic
mmcm_lock_out	PPI	Output	MMCM lock indication Active-High
clk_hs_txp	PPI	Output	D-PHY clock lane serial lines
clk_hs_txn			
data_hs_txp[N:0]	PPI	Output	D-PHY data lane serial lines Width of these ports is equal to the number of lanes
data_hs_txn[N:0]			
clk_lp_txp	PPI	Output	D-PHY LP clock lane serial lines
clk_lp_txn			
data_lp_txp[N:0]	PPI	Output	D-PHY LP serial lines Width of these ports is equal to the number of lanes
data_lp_txn[N:0]			

**DPHY Interface (UltraScale+™) Shared Logic in the Core**

xiphy_byteclk_out	PPI	Output	Goes as an input to PHY Used to transmit high-speed data
clkoutphy_out	PPI	Output	PHY serial clock
pll_lock_out	PPI	Output	PLL lock indication
txbyteclkhs	PPI	Output	txbyteclkhs frequency for D-PHY TX when the shared logic is inside the core Frequency is <code>line_rate/8.0</code>
clk_txp/n	PPI	Output	DPHY clock lane serial lines
data_txp[N:0]/n[N:0]	PPI	Output	DPHY data lane serial lines Width of these ports is equal to the number of lanes

**DPHY Interface (UltraScale+) Shared Logic in Example Design**

clk_txp	PPI	Output	D-PHY clock lane serial lines
clk_txn			
data_txp[N:0]	PPI	Output	D-PHY data lane serial lines Width of these ports is equal to the number of lanes
xiphy_byteclk_in	PPI	Input	Connect the <code>xiphy_byteclk</code> pin
clkoutphy_in	PPI	Input	Connect the <code>clkoutphy</code> pin

**Table 2-1: Port Descriptions (Cont'd)**

Signal name	Interface	Direction	Description
pll_lock_in	PPI	Input	Connect the PLL Pins Active-High
txclkes_in	PPI	Input	Escape clock
system_rst_in	PPI	Input	Active-High system reset
txbyteclkhs_in	PPI	Input	Byteclkhs for D-PHY TX when shared logic is in example design Frequency is line_rate/8.0
<b>DPHY Interface (7 Series Family) Shared Logic in Example Design</b>			
txclkes_in	PPI	Input	Escape Clock
oserdes_clk_in	PPI	Input	Connect the OSERDES CLK pin Frequency is line_rate/2.
txbyteclkhs_in	PPI	Input	Frequency for D-PHY TX when Shared Logic is in example design Frequency is line_rate/8.0
system_rst_in	PPI	Input	Active-high system reset
clk_hs_txp	PPI	Output	D-PHY clock lane serial lines
clk_hs_txn			
data_hs_txp[N:0]	PPI	Output	D-PHY data lane serial lines Width of these ports is equal to the number of lanes
data_hs_txn[N:0]			
clk_lp_txp	PPI	Output	D-PHY LP Clock Lane Serial Line
clk_lp_txn			
data_lp_txp[N:0]	PPI	Output	D-PHY LP serial lines Width of these ports is equal to the number of lanes
data_lp_txn[N:0]			
<b>AXI4-Lite Interface</b>			
s_axi_*	S_AXI	-	AXI4-lite interface
<b>AXI4-Stream Input Interface</b>			
s_axis_aclk	System	Input	AXI clock (same clock for lite and stream interface)
s_axis_aresetn	System	Input	AXI reset. Active-Low (same reset for lite and stream interface)
s_axis_tready	S_AXIS	Output	Driven by the CSI2 TX controller Indicates that the controller is ready to accept the data

**Table 2-1: Port Descriptions (Cont'd)**

Signal name	Interface	Direction	Description
s_axis_tvalid	S_AXIS	Input	Indicates that the data on s_axis_tdata is valid When high, and is the first pixel of the line, it validates the following signals: <ul style="list-style-type: none"><li>• s_axis_tdest</li><li>• s_axis_tuser[47:32]</li><li>• s_axis_tuser[63:48]</li></ul>
s_axis_tlast	S_AXIS	Input	Indicates the line end and is triggered on last pixel of every line
s_axis_tdata[N-1:0]	S_AXIS	Input	AXI4-stream interface Width of this port is dependent on the pixel type and the number of pixels per beat
s_axis_tdest[1:0]	S_AXIS	Input	AXI4-stream interface Virtual channel identifier
s_axis_tuser[95:0]	S_AXIS	Input	AXI4-stream sideband interface <ul style="list-style-type: none"><li>• 95-64 Reserved</li><li>• 63-48 Word count</li><li>• 47-32 Line number</li><li>• 31-16 Frame number</li><li>• 6-1 Data type</li><li>• 0 Frame start</li></ul>
<b>Native Video Interface</b>			
vid_vsync	Video	Input	Active-High vertical sync
vid_hsync	Video	Input	Active-High horizontal sync
vid_enable	Video	Input	Active-High pixel data enable
vid_pxl[N-1:0]	Video	Input	Video Data Width of this port is dependent on pixel type and the number of pixels per beat Sampled at when vid_enable is high
vid_vc[1:0]	Video	Input	Virtual Channel Identifier Sampled at the rising edges of vid_vsync or vid_hsync or vid_enable
vid_di[5:0]	Video	Input	Indicates the Data ID of the incoming long packet Sampled on the rising edges of vid_hsync
vid_linenum[15:0]	Video	Input	Line number to use Sampled at Hsync rising edge
vid_framenum[15:0]	Video	Input	Frame number to use Sampled at Vsync rising edge
vid_wc[15:0]	Video	Input	Word count of the long packet Sampled at Hsync rising edge

**Table 2-1: Port Descriptions (Cont'd)**

Signal name	Interface	Direction	Description
<b>System Interface</b>			
Interrupt	System	Output	System interrupt output

The core adds data ID implicitly on detection for the synchronization of short packets such as Frame Start/End, and Line Start/End. For more details, refer [Appendix B, Debugging](#).

**Table 2-2** lists the axis ports and their values when you want to drive Data Type = RAW8, Horizontal Pixels = 3840 on Virtual Channel (V.C) = 3 on an AXI streaming interface.

**Table 2-2: Port Values on AXI4-Stream Interface**

Port	Value
s_axis_tuser[6-1]	0x2A
s_axis_tuser[63-48]	0x0F00
s_axis_tdest[1:0]	0x3

**Table 2-3** lists the native ports and their values when you want to drive Data Type = RAW12, Horizontal Pixels = 3840 on Virtual Channel (V.C) = 2 on a native video interface.

**Table 2-3: Port Values on Native Video Interface**

Port	Value
vid_di[5:0]	0x2C
vid_wc[15:0]	0x1680
vid_vc[1:0]	0x2

## Pixel Encoding

This section elaborates the pixel encoding and the s\_axis\_tdata or the vid\_pxl port width generation followed by the MIPI CSI-2 TX controller. For more details, refer *AXI4-Stream Video IP and System Design Guide (UG934)*[Ref 2].

The width of the s\_axis\_tdata or the vid\_pxl port is calculated as shown below:

Data Width = Byte aligned of (14\*3\*Pixel Mode)

For example, the data width for 1 Pixel Mode is  $14*3*1$  resulting in 42. Therefore, the width has to be byte aligned with the final Data Width, which in this case is 48 ([47:0]).

[Table 2-4](#) lists the pixel encoding for single pixel per beat.

**Table 2-4: Pixel Encoding for Single Pixel per Beat**

Generic	[12DW-1: 11DW]	[11DW-1: 10DW]	[10DW-1: 9DW]	[9DW-1: 8DW]	[8DW-1: 7DW]	[7DW-1: 6DW]	[6DW-1: 5DW]	[5DW-1: 4DW]	[4DW-1: 3DW]	[3DW-1: 2DW]	[2DW-1: DW]	[DW-1:0]
Boundary	[167:154]	[153:140]	[139:126]	[125:112]	[111:98]	[97:84]	[83:70]	[69:56]	[55:42]	[41:28]	[27:14]	[13:0]
Data Type												
RAW8, USD, Embedded non-image data												P0[13:6]
RAW10												P0[13:4]
RAW12												P0[13:2]
RAW14												P0[13:0]
YUV422-8 Bit												U0/ V0[27:20] Y0/ Y1[13:6]
RGB888										R0[41:34]	B0[27:20]	G0[13:6]
RGB565										R0[41:37]	B0[27:23]	G0[13:8]

[Table 2-5](#) lists the pixel encoding for dual pixel per beat.

**Table 2-5: Pixel Encoding for Dual Pixel per Beat**

Generic	[12DW-1: 11DW]	[11DW-1: 10DW]	[10DW-1: 9DW]	[9DW-1: 8DW]	[8DW-1: 7DW]	[7DW-1: 6DW]	[6DW-1: 5DW]	[5DW-1: 4DW]	[4DW-1: 3DW]	[3DW-1: 2DW]	[2DW-1: DW]	[DW-1:0]
Boundary	[167:154]	[153:140]	[139:126]	[125:112]	[111:98]	[97:84]	[83:70]	[69:56]	[55:42]	[41:28]	[27:14]	[13:0]
Data Type												
RAW8, USD, Embedded non-image data											P1[27: 20]	P0[13:6]
RAW10											P1[27: 18]	P0[13:4]
RAW12											P1[27: 16]	P0[13:2]
RAW14											P1[27: 14]	P0[13:0]
YUV422-8Bit										V0[55: 48] Y1[41: 34] U0[27: 20]	Y0[13:6]	
RGB888								R1[83: 76] B1[69: 62] G1[55: 48]	R0[41: 34] B0[27: 20]	G0[13:6]		
RGB565							R1[83: 79] B1[69: 65] G1[55: 50]	R0[41: 37] B0[27: 23]	G0[13:8]			

[Table 2-6](#) lists the pixel encoding for quad pixel per beat.

**Table 2-6: Pixel encoding for Quad Pixel per Beat**

Generic	[12DW-1: 11DW]	[11DW-1: 10DW]	[10DW-1: 9DW]	[9DW-1: 8DW]	[8DW-1: 7DW]	[7DW-1: 6DW]	[6DW-1: 5DW]	[5DW-1: 4DW]	[4DW-1: 3DW]	[3DW-1: 2DW]	[2DW-1: DW]	[DW-1:0]
Boundary	[167:154]	[153:140]	[139:126]	[125:112]	[111:98]	[97:84]	[83:70]	[69:56]	[55:42]	[41:28]	[27:14]	[13:0]
Data Type												
RAW8, USD, Embedded non-image data									<b>P3[55: 48]</b>	<b>P2[41: 34]</b>	<b>P1[27: 20]</b>	<b>P0[13:6]</b>
RAW10									<b>P3[55: 46]</b>	<b>P2[41: 32]</b>	<b>P1[27: 18]</b>	<b>P0[13:4]</b>
RAW12									<b>P3[55: 44]</b>	<b>P2[41: 30]</b>	<b>P1[27: 16]</b>	<b>P0[13:2]</b>
RAW14									<b>P3[55: 42]</b>	<b>P2[41: 28]</b>	<b>P1[27: 14]</b>	<b>P0[13:0]</b>
YUV422-8Bit					<b>V2[11: 1:104]</b>	<b>Y3[97: 90]</b>	<b>U2[83: 76]</b>	<b>Y2[69: 62]</b>	<b>VO[55: 48]</b>	<b>Y1[41: 34]</b>	<b>U0[27: 20]</b>	<b>Y0[13:6]</b>
RGB888	<b>R3[167: 160]</b>	<b>B3[153: 146]</b>	<b>G3[139: 132]</b>	<b>R2[125: 118]</b>	<b>B2[111: 104]</b>	<b>G2[9: 7:90]</b>	<b>R1[83: 76]</b>	<b>B1[69: 62]</b>	<b>G1[55: 48]</b>	<b>R0[41: 34]</b>	<b>B0[27: 20]</b>	<b>G0[13:6]</b>
RGB565	<b>R3[167: 163]</b>	<b>B3[153: 149]</b>	<b>G3[139: 134]</b>	<b>R2[125: 121]</b>	<b>B2[111: 107]</b>	<b>G2[9: 7:92]</b>	<b>R1[83: 79]</b>	<b>B1[69: 65]</b>	<b>G1[55: 50]</b>	<b>R0[41: 37]</b>	<b>B0[27: 23]</b>	<b>G0[13:8]</b>

## Register Space

This section details registers available in the MIPI CSI-2 TX Subsystem. The address map is split into following regions:

- MIPI CSI-2 TX Controller core
- MIPI D-PHY core

Each IP core is given an address space of 32K. Example offset addresses from the system base address when the MIPI D-PHY registers are enabled are shown in [Table 2-7](#).

**Table 2-7: Sub-Core Address Offsets**

IP Cores	Offset
MIPI CSI-2 TX Controller	0x0000
MIPI D-PHY	0x1000

## MIPI CSI-2 TX Controller Core Registers

**Table 2-8** specifies the name, address, and description of each firmware addressable register within the MIPI CSI-2 TX controller core.

**Table 2-8: MIPI CSI-2 TX Controller Core Registers**

Address Offset	Register Name	Description
0x00	Core Configuration	Core configuration options
0x04	Protocol Configuration	Protocol configuration options
0x08	Reserved <sup>(1)</sup>	
0x0C	Reserved	
0x10	Reserved	
0x14	Reserved	
0x18	Reserved	
0x1C	Reserved	
0x20	Global Interrupt Enable	Global interrupt enable registers
0x24	Interrupt status	Interrupt status register
0x28	Interrupt enable	Interrupt enable register
0x2C	Reserved	
0x30	Generic short packet Entry	Entry for the generic short packets
0x34	Reserved	
0x38	Reserved	
0x3C	Reserved	
0x40	Reserved	
0x44	Reserved	
0x48	Reserved	
0x4C	Reserved	
0x50	Reserved	
0x54	Reserved	
0x58	Reserved	
0x5C	Reserved	
0x60	Reserved	
0x64	Reserved	
0x68	Reserved	
0x6C	Reserved	
0x70	Reserved	
0x74	Reserved	
0x78	Generic Short Packet Status	Generic short packet FIFO status

**Table 2-8: MIPI CSI-2 TX Controller Core Registers (Cont'd)**

Address Offset	Register Name	Description
0x7C	Reserved	

**Notes:**

- Access type and reset value for all the reserved bits in the registers is read-only with value 0.
- Register accesses should be word aligned and there is no support for a write strobe. WSTRB is not used internally.
- Only the lower 7 bits (6:0) of the read and write address of the AXI4-Lite interface are decoded. This means that accessing address 0x00 and 0x80 results in reading the same address of 0x00.
- Reads and writes to addresses outside this table do not return an error.

### **Core Configuration Register**

The Core Configuration register is described in [Table 2-9](#) and allows you to enable and disable the MIPI CSI-2 TX Controller core and apply a soft reset during core operation.

**Table 2-9: Core Configuration Register**

Bits	Name	Reset Value	Access	Description
31–5	Reserved	N/A	N/A	Reserved Not used by the core Recommended to write 0
4	Clock Mode	0x0	R/W	Clock mode configuration 0: Continuous clock mode 1: Non-continuous clock mode
3	ULPS Mode	0x0	R/W	Drives the lane into ULPS mode 0: Exit 1: Entry
2	Controller Ready	0x1	R	Controller is ready for processing During soft-reset or core disable, rely on this status to ensure if the core has stopped all its activity 1: Controller is Ready 0: Controller is Inactive
1	Soft Reset	0x0	R/W	Soft reset to core 1: Resets the ISR bits only 0: Takes the core out of soft reset Once the soft reset is released, core starts capturing new status information to ISR

**Table 2-9: Core Configuration Register (Cont'd)**

Bits	Name	Reset Value	Access	Description
0	Core Enable	0x0	R/W	<p>1: Enables the core to receive and process packets 0<sup>(1)</sup>: Disables the core for operation</p> <ul style="list-style-type: none"> <li>When disabled, the controller ends the current transfer by resetting all internal FIFOs and registers</li> <li>When enabled, the controller starts transferring the vsync packet (a new video frame)</li> </ul>

**Notes:**

- When the Core is Disabled (Core Enable is set to 0), you can write into the registers, but the CSI2 TX Controller captures the value only after the core is Enabled (Core Enable is set to 1). The controller also ignores the writes to the Generic Short Packet Entry Register.

### **Protocol Configuration Register**

The Protocol Configuration register is described in [Table 2-10](#) and allows you to configure protocol specific options such as the number of lanes to be used.

**Table 2-10: Protocol Configuration Register**

Bits	Name	Reset Value	Access	Description
31–16	Reserved	N/A	N/A	Reserved Not used by the core
15	Line start/End Generation	0x0	R/W	<p>Line synchronization packet generation 0: Do not generate line start/end 1: Generate line start/end</p> <p><b>Note:</b> Writing this bit might have an impact from the immediate received line, after the change in the configuration.</p>
14–13	Pixel Mode	0x0	R	Configured pixel mode 0x0—1 pixel mode 0x1—2 pixel mode 0x3—4 pixel mode
12–5	Reserved	N/A	N/A	Reserved
4–3	Maximum Lanes	Number of lanes configured during core generation	R	Maximum lanes of the core 0x0—1 Lane 0x1—2 Lanes 0x2—3 Lanes 0x3—4 Lanes
2	Reserved	N/A		Reserved

**Table 2-10: Protocol Configuration Register (Cont'd)**

Bits	Name	Reset Value	Access	Description
1–0	Active Lanes	Number of lanes configured during core generation	R/W	Configured lanes in the core <sup>(1)</sup> 0x0—1 Lane 0x1—2 Lanes 0x2 —3 Lanes 0x3—4 Lanes

**Notes:**

- When the Active Lanes option is disabled, the Maximum Lanes, and the Active Lanes register fields hold the same value.

### **Global Interrupt Enable Register**

The Global Interrupt Enable register is described in [Table 2-11](#).

**Table 2-11: Global Interrupt Enable Register**

Bits	Name	Reset Value	Access	Description
31–1	Reserved	N/A	N/A	Reserved Not used by the core
0	Global Interrupt enable	0x0	R/W	Master enable for the device interrupt output to the system 1: Enabled—the corresponding Interrupt Enable register (IER) bits are used to generate interrupts 0: Disabled—Interrupt generation blocked irrespective of IER bits <b>Note:</b> Writing to this bit has an immediate effect.

### **Interrupt Status Register**

The Interrupt Status register (ISR) is described in [Table 2-12](#) and captures the error and status information for the core.

**Table 2-12: Interrupt Status Register**

Bits	Name	Reset Value	Access <sup>(1)</sup>	Description
31–6	Reserved	N/A	N/A	Reserved Not used by the core
5	Incorrect Lane Configuration	0x0	R/W1C	Asserted when the Active Lanes is greater than the maximum lanes in the protocol configuration register
4	Generic Short Packet (GSP) FIFO Full	0x0	R/W1C	Asserted when the Generic Short Packet FIFO is full
3	ULPS state	0x0	R/W1C	0: Indicates that the D-PHY lanes have exited the ULPS state or are not in the ULPS state 1: Indicates that the D-PHY lanes are in the ULPS state

**Table 2-12: Interrupt Status Register (Cont'd)**

Bits	Name	Reset Value	Access <sup>(1)</sup>	Description
2	Line Buffer Full	0x0	R/W1C	Asserted when the Line Buffer is Full
1	Unsupported/Reserved Data Type	0x0	R/W1C	Asserted when the unsupported or the reserved data types are seen in the generic short packet request
0	Pixel Data Underrun	0x0	R/W1C	Asserted when the core starves for pixel data during the packet transmission

**Notes:**

1. W1C = Write 1 to clear.

### **Interrupt Enable Register**

The Interrupt Enable register (IER) is described in [Table 2-13](#) and allows you to selectively generate an interrupt at the output port for each error/status bit in the ISR. An IER bit set to 0 does not inhibit an error/status condition from being captured, but inhibits it from generating an interrupt.

**Table 2-13: Interrupt Enable Register**

Bits	Name	Reset Value	Access	Description
31-6	Reserved	N/A	N/A	Reserved Not used by the core
5	Incorrect Lane Configuration Enable	0x0	R/W	Generate interrupt on incorrect lane configuration
4	Generic Short Packet (GSP) FIFO Full Enable	0x0	R/W	Generate interrupt on GSP FIFO full
3	ULPS State Enable	0x0	R/W	Generate interrupt on ULPS state
2	Line Buffer Full Enable	0x0	R/W	Generate interrupt when the line buffer is full
1	Unsupported/Reserved Data Type Enable	0x0	R/W	Generate interrupt on unsupported or reserved data type
0	Pixel Data Underrun Enable	0x0	R/W	Generate interrupt on the pixel data underrun condition

### **Generic Short Packet Entry Register**

The Generic Short Packet Entry register is described in [Table 2-14](#). Only generic short packets are supported (data types from 0x08 to 0x0F).

**Table 2-14: Generic Short Packet Entry Register**

Bits	Name	Reset Value	Access	Description
31–24	Reserved	N/A	N/A	Reserved
23–16	Byte-1	0x0	R/W	Byte 1 of the short packet
15–8	Byte-0	0x0	R/W	Byte 0 of the short packet
7–6	VC	0x0	R/W	VC value of the short packet
5–0	Data type	0x0	R/W	Short packet data type

### **Generic Short Packet Status Register**

The Generic Short Packet Status register is described in [Table 2-15](#). This register indicates the number of generic short packets (GSP) that can be written safely.

**Table 2-15: Clock Lane Information Register**

Bits	Name	Reset Value	Access	Description
31–5	Reserved	N/A	N/A	Reserved
5–0	Generic Short Packet Vacancy	0x20	R	Number of generic short packets that can be safely written to the Generic Short Packet FIFO, before it goes full

## **MIPI D-PHY Registers**

The MIPI D-PHY registers are available when **D-PHY Register Interface** is selected in Vivado IDE. For details about MIPI D-PHY registers, see the *MIPI D-PHY LogiCORE IP Product Guide (PG202)* [[Ref 3](#)].

# Designing with the Subsystem

This chapter includes guidelines and additional information to facilitate designing with the subsystem.

---

## General Design Guidelines

The subsystem fits into a image sensor pipe transmission path. The input to the subsystem must be connected to a AXI4-S stream source or Native stream source which generates the pixel data. The output of the subsystem is a MIPI complaint serial data. Because the MIPI protocol does not allow throttling on the output interface (PPI), the module connected to the output of this subsystem should have sufficient bandwidth for the data generated by the image sensor.

The Protocol Configuration Register [1:0] can be used to dynamically configure the active lanes used by the subsystem using the following guidelines:


1. Program the required lanes in the Protocol Configuration register only when the following conditions are met:
    - a. “Enable Active Lanes” is set in the Vivado IDE
    - b. There is no ongoing transfer on the PPI and all the data lanes are in the stop-state
  2. Do not send the new updated lanes traffic until the read from Protocol Configuration registers reflects the new value.
- 

## Shared Logic


Shared Logic provides a flexible architecture that works both as a stand-alone subsystem and as part of a larger design with one or more subsystem instances. This minimizes the amount of HDL modifications required, but at the same time retains the flexibility of the subsystem.

Shared logic in the CSI-2 TX Subsystem allows you to share MMCMs and PLLs with multiple instances of the CSI-2 TX Subsystem within the same I/O bank.

There is a level of hierarchy called <component\_name>\_support. Figure 3-1 and Figure 3-2 show two hierarchies where the shared logic is either contained in the subsystem or in the example design. In these figures, <component\_name> is the name of the generated subsystem. The difference between the two hierarchies is the boundary of the subsystem. It is controlled using the Shared Logic option in the Vivado IDE Shared Logic tab for the MIPI CSI-2 TX Subsystem. The shared logic comprises an MMCM, a PLL and some BUFGs (maximum of 4).



*Figure 3-1: Shared Logic Included in the Subsystem*



X16321-033116

*Figure 3-2: Shared Logic Outside Subsystem*

## Shared Logic in the Core

Selecting **Shared Logic in the Core** implements the subsystem with the MMCM and PLL inside the subsystem to generate all the clocking requirement of the PHY layer.

Select **Include Shared Logic in Core** if:

- You do not require direct control over the MMCM and PLL generated clocks

- You want to manage multiple customizations of the subsystem for multi-subsystem designs
- This is the first MIPI CSI-2 TX Subsystem in a multi-subsystem system

These components are included in the subsystem, and their output ports are also provided as subsystem outputs.

## Shared Logic in Example Design

The MMCMs and PLLs are outside this subsystem instance.

Select **Include Shared Logic in example design** if:

- This is the second MIPI CSI-2 TX Subsystem instance in a multi-subsystem design
- You only want to manage one customization of the MIPI CSI-2 TX Subsystem in your design
- You want direct access to the input clocks

To fully utilize the MMCM and PLL, customize one MIPI CSI-2 TX Subsystem with shared logic in the subsystem and one with shared logic in the example design. You can connect the MMCM/PLL outputs from the first MIPI CSI-2 TX Subsystem to the second subsystem.


If you want fine control you can select **Include Shared Logic in example design** and base your own logic on the shared logic produced in the example design.

[Figure 3-3](#) shows the sharable resource connections from the MIPI CSI-2 TX Subsystem with shared logic included (MIPI\_CSI\_SS\_Master) to the instance of another MIPI CSI-2 TX Subsystem without shared logic (MIPI\_CSI\_SS\_Slave00 and MIPI\_CSI\_SS\_Slave01).

## I/O Planning

The MIPI D-PHY core provides an I/O planner feature for I/O selection. You can select any I/O for the clock and data lanes in the TX core configuration for the selected HP I/O bank.

Eight D-PHY IP cores can be implemented per I/O bank due to BITSLICE and BITSLICE\_CONTROL instances in the UltraScale+ devices.



*Figure 3-3: Shared Logic in the Example Design*

**Note:** The master and slave subsystems should be configured with the same line rate when sharing MMCM/PLL resources.

# Clocking

The subsystem clocks are described in [Table 3-1](#).

*Table 3-1: Subsystem Clocks*

Clock Name	Description
txByteClkhs	Clock used to transfer on the PPI interface signals
s_axis_aclk	Clock used to perform all core operation blocks

The register interface also works on the s\_axis\_aclk core clock. Selection of s\_axis\_aclk is based on TxByteClk.

When the effective pixel width is less than or equal to ( $\leq$ ) 32, the s\_axis\_aclk should be selected such that the input bandwidth is at least 20-30% more than the output bandwidth. For example,  $s\_axis\_aclk * Pixel\_width * Pixel\_Mode > TxByteClk * No\_Lanes * 8$ .

Where  $s\_axis\_aclk * Pixel\_width * Pixel\_Mode$  is approximately equal to 1.2 or 1.3 times of  $(TxByteClk * No\_Lanes * 8)$ .

When the effective pixel is greater than ( $>$ ) 32, the s\_axis\_aclk should be selected such that the input bandwidth is at least more than 2-3 times the output bandwidth. For example,  $s\_axis\_aclk * Pixel\_width * Pixel\_Mode > TxByteClk * No\_Lanes * 8$ .

Where  $s\_axis\_aclk * Pixel\_width * Pixel\_Mode$  is approximately equal to 2 or 3 times of  $(TxByteClk * No\_Lanes * 8)$ .

**Note:** If the above relations are not met, the MIPI CSI-2 TX controller will report an under-run condition.

*Table 3-2: Clocking Examples for Different Combinations*

Data Type	Line Rate (Mb/s)	txByteClkhs(MHz)	Lanes	Pixel Mode	s_axis_aclk(MHz)
RAW8	1200	150	1	1	180
RAW10	900	112.5	2	2	117
RAW12	1000	125	3	4	125
RGB888	800	100	4	4	100
RAW14	500	62.5	2	2	42.8
RGB565	1000	125	1	2	40
YUV-422-8 Bit	1500	187.5	3	4	140.6

**Note:** For data type interleaving with native video interface, select data types with similar pixel widths to avoid under-run or line buffer full. For example, RAW8, RAW10.

## Resets

The MIPI CSI-2 Transmitter Controller has one hard reset (`s_axis_aresetn`) and one register based reset (soft reset).


- `s_axis_aresetn`: All the core logic blocks reset to power-on conditions including registers.
- The soft reset resets the Interrupt Status register (ISR) of MIPI CSI-2 TX Controller and does not affect the core processing.

The subsystem has one external reset port:

- `s_axis_aresetn`: Active-Low reset for the subsystem blocks

The duration of `s_axis_aresetn` should be a minimum of 40 `dphy_clk_200M` cycles to propagate the reset throughout the system.

The reset sequence is shown in [Figure 3-4](#).



*Figure 3-4: Shared Logic Outside Subsystem*

[Table 3-3](#) summarizes all resets available to the MIPI CSI-2 TX Subsystem and the components affected by them.

*Table 3-3: Subsystem Components*

Sub-core	<code>s_axis_aresetn</code>
MIPI CSI-2 TX Controller	Connected to <code>s_axi_aresetn</code> core port
MIPI DPHY	Inverted signal connected to <code>core_rst</code> port
AXI Crossbar	Connected to <code>aresetn</code> port

**Note:** The effect of each reset (`s_axis_aresetn`) is determined by the ports of the sub-cores to which they are connected. See the individual sub-core product guides for the effect of each reset signal.

# Protocol Description

## Programming Sequence

This section contains the programming sequence for the subsystem. Program and enable the components of subsystem in the following order:

1. MIPI CSI-2 TX Controller
2. MIPI D-PHY (if register interface is enabled)

## Address Map Example

[Table 3-4](#) shows an example based on a subsystem base address of 0x44A0\_0000 (32 bits) when the MIPI D-PHY register interface is enabled.


*Table 3-4: Address Map Example*

Core	Base address
MIPI CSI-2 TX Controller	0x0000
MIPI D-PHY	0x1000

## MIPI CSI-2 TX Controller Core Programming

The MIPI CSI-2 TX Controller programming sequence is as follows. [Figure 3-6](#), [Figure 3-6](#), and [Figure 3-7](#) show a graphical representation of the sequence:


1. Configure the registers and enable the core
  - a. Read the [Core Configuration Register](#) to ensure that the controller ready bit is set to 1, before enabling the core anytime (for example, after reset or after disabling the core).
  - b. Configure the required configuration through register programming.
  - c. Enable the core and send video stream on input interface.
  - d. All along this sequence, either continuously poll or wait for external interrupt (if enabled) and read interrupt status register for any errors or status reported.



*Figure 3-5: Core Programming Sequence - Enable the core*

2. Disabling and re-enabling the core


- Disable the core using the [Core Configuration Register](#) (set the Core Enable bit to 0).
- Wait until the controller ready bit is set in the [Core Configuration Register](#).
- Re-enable the core (set the Core Enable bit to 1)



*Figure 3-6: Core Programming Sequence - Disable and Re-enable the Core*

### 3. ULPS Entry and ULPS Exit

- Drive the PHY Lanes to ULPS Mode, write 1 into the [Core Configuration Register](#) (set the ULPS Mode bit to 1).
- Corresponding PPI Signals are driven to the PHY (`txrequestesc`, `txulpseesc`) for the entry into the ULPS State.
- After the PHY Lanes have entered into the ULPS State (`ulpsactivenot` goes low) the Interrupt Status register is updated with the corresponding status.
- Exit the ULPS state, write 0 into the [Core Configuration Register](#) (set the ULPS Mode bit to 0).
- Corresponding PPI Signal is driven to the PHY (`txulpsexit`) for exiting from the ULPS State.
- PPI deasserts the `txrequestesc` after a millisecond of deassertion of the `ulpsactivenot` signal. The ULPS exit is indicated through the Interrupt Status register.



*Figure 3-7: Core Programming Sequence - ULPS Entry and ULPS Exit*

### **MIPI D-PHY IP Core Programming**

See the *MIPI D-PHY LogiCORE IP Product Guide (PG202)* [Ref 3] for MIPI D-PHY IP core programming details.

# Design Flow Steps

This chapter describes customizing and generating the subsystem, constraining the subsystem, and the simulation, synthesis and implementation steps that are specific to this subsystem. More detailed information about the standard Vivado® design flows and the IP integrator can be found in the following Vivado Design Suite user guides:

- *Vivado Design Suite User Guide: Designing IP Subsystems using IP Integrator* (UG994) [\[Ref 8\]](#)
  - *Vivado Design Suite User Guide: Designing with IP* (UG896) [\[Ref 9\]](#)
  - *Vivado Design Suite User Guide: Getting Started* (UG910) [\[Ref 10\]](#)
  - *Vivado Design Suite User Guide: Logic Simulation* (UG900) [\[Ref 11\]](#)
- 

## Customizing and Generating the Subsystem

This section includes information about using Xilinx tools to customize and generate the subsystem in the Vivado Design Suite.

If you are customizing and generating the subsystem in the Vivado IP integrator, see the *Vivado Design Suite User Guide: Designing IP Subsystems using IP Integrator* (UG994) [\[Ref 8\]](#) for detailed information. IP integrator might auto-compute certain configuration values when validating or generating the design. To check whether the values do change, see the description of the parameter in this chapter. To view the parameter value, run the `validate_bd_design` command in the Tcl console.


You can customize the IP for use in your design by specifying values for the various parameters associated with the subsystem using the following steps:

1. Select the IP from the Vivado IP catalog.
2. Double-click the selected IP or select the **Customize IP** command from the toolbar or right-click menu.

For details, see the *Vivado Design Suite User Guide: Designing with IP* (UG896) [Ref 9] and the *Vivado Design Suite User Guide: Getting Started* (UG910) [Ref 10].

**Note:** Figures in this chapter are illustrations of the Vivado Integrated Design Environment (IDE). The layout depicted here might vary from the current version.

The subsystem configuration screen is shown in [Figure 4-1](#).



*Figure 4-1: Subsystem Customization Screen-Configuration Tab Page*

**Component Name:** The Component Name is used as the name of the top-level wrapper file for the subsystem. The underlying netlist still retains its original name. Names must begin with a letter and must be composed from the following characters: a through z, 0 through 9, and "\_". The default is `mipi_csi2_tx_subsystem_0`.

## Configuration Tab

The Configuration tab page provides core related configuration parameters.

**Input Video Interface:** Select the video interface used to accept pixel data. Values are AXI4S and Native.

**Input Pixels per beat:** Select the number of input pixels per clock on input interface. Values are 1 (single pixel), 2 (dual pixel), or 4(quad pixel).

**Line Buffer Depth:** Select the depth of internal RAM based on the bandwidth requirement such that the line buffer does not overflow. Values are 128, 256, 512, 1024, 2048, 4096, 8192 or 16384.

**CSI Lanes:** Select the maximum number of D-PHY lanes for this subsystem instance. Values are 1, 2, 3, or 4.

**CRC Generation Logic:** When set, CRC computation is performed and appended to the payload data.

**Enable Active Lanes:** When set, the core supports the dynamic configuration of the number of active lanes from the maximum number of lanes selected during core generation using the parameter **CSI Lanes**. For example, when **CSI Lanes** is set to 3, the number of active lanes can be programmed using the protocol configuration register to be 1,2 or 3. The core reports an error when the active lanes setting is greater than the serial lanes setting through the interrupt status register, bit 5.

**Line Rate (Mb/s):** Selects the line rate for the MIPI D-PHY core. Maximum line rate for the UltraScale+ devices is 1500 Mb/s, and for the 7 Series is 1250 Mb/s.

**Enable AXI-4 Lite Register I/F:** Select to enable the register interface for the MIPI D-PHY core.


### Infer OBUFTDS for 7 series HS outputs

Select this option to infer OBUFTDS for HS outputs.

**Note:** This option is available only for 7 Series D-PHY TX configuration. It is recommended to use this option for D-PHY compatible solution based on resistive circuit. For details, see *D-PHY Solutions* (XAPP894) [Ref 15].

## Shared Logic Tab

The Shared Logic tab page provides shared logic inclusion parameters. The subsystem shared logic configuration screen is shown in [Figure 4-2](#).



*Figure 4-2: Subsystem Customization Screen-Shared Logic Tab Page*


**Shared Logic:** Select whether the MMCM and PLL are included in the core or in the example design. Values are:

- Include Shared Logic in core
- Include Shared Logic in example design

## Pin Assignment Tab

The Pin Assignment tab page allows to select pins. The subsystem pin assignment configuration screen is shown in [Figure 4-3](#).

**Note:** This tab is not available for 7 Series device configurations.



*Figure 4-3: Subsystem Customization Screen-Pin Assignment Tab Page*

**HP IO Bank Selection:** Select the HP I/O bank for clock lane and data lane implementation.

**Clock Lane:** Select the LOC for clock lane. This selection determines the I/O byte group within the selected HP I/O bank.

**Data Lane 0/1/2/3:** Displays the Data lanes 0,1,2, and 3 LOC based on the clock lane selection.

## User Parameters

**Table 4-1** shows the relationship between the fields in the Vivado IDE and the User Parameters (which can be viewed in the Tcl Console).

**Table 4-1: Vivado IDE Parameter to User Parameter Relationship**

Vivado IDE Parameter	User Parameter	Default Value
CSI Lanes	C_CSI_LANES	4
Enable Active Lanes	C_CSI_EN_ACTIVELANES	0
Input Pixels per beat	C_CSI_PIXEL_MODE	1
Line Buffer Depth	C_CSI_LINE_BUFR_DEPTH	2048
CRC Generation Logic	C_CSI_CRC_ENABLE	1
Input Video Interface	C_CSI_VID_INTERFACE	AXI4_Stream
Line Rate (Mb/s)	C_HS_LINE_RATE	1000
Enable AXI-4 Lite Register I/F	C_DPHY_EN_REGIF	0
Shared Logic	SupportLevel	0
Infer OBUFTDS for 7 series HS outputs	C_EN_HS_OBUFTDS	0
HP IO Bank Selection	HP_IO_BANK_SELECTION	Value based on part selected.
Clock Lane	CLK_LANE_IO_LOC	Value based on part selected
Data Lane0	DATA_LANE0_IO_LOC	Value based on part selected
Data Lane1	DATA_LANE1_IO_LOC	Value based on part selected
Data Lane2	DATA_LANE2_IO_LOC	Value based on part selected
Data Lane 3	DATA_LANE3_IO_LOC	Value based on part selected

## Output Generation

For details, see the *Vivado Design Suite User Guide: Designing with IP* (UG896) [Ref 9].

---

## Constraining the Subsystem

This section contains information about constraining the subsystem in the Vivado Design Suite.

## Required Constraints

This section is not applicable for this subsystem.

## Device, Package, and Speed Grade Selections

This section is not applicable for this subsystem.

## Clock Frequencies

See [Clocking](#).

## Clock Management

The MIPI CSI-2 TX Subsystem sub-core MIPI D-PHY uses an MMCM to generate the general interconnect clocks, and the PLL is used to generate the serial clock and parallel clocks for the PHY. The input to the MMCM is constrained as shown in Clock Frequencies section of *MIPI D-PHY LogiCORE IP Product Guide (PG202)* [Ref 3]. No additional constraints are required for the clock management.

## Clock Placement

This section is not applicable for this subsystem.

## Banking

The MIPI CSI-2 TX Subsystem provides the Pin Assignment Tab option to select the HP I/O bank. Clock lane and data lane(s) are implemented on the selected I/O bank BITSLICE(s).

## Transceiver Placement

This section is not applicable for this subsystem.

## I/O Standard and Placement

The MIPI standard serial I/O ports should use MIPI\_DPHY\_DCI for the I/O standard in the XDC file for UltraScale+ family. The LOC and I/O standards must be specified in the XDC file for all input and output ports of the design. The MIPI CSI-2 TX Subsystem MIPI D-PHY sub-core generates the I/O pin LOC for the pins that are selected during IP customization for UltraScale+ designs. No I/O pin LOC are provided for 7 Series MIPI D-PHY IP designs. You have to manually select the clock capable I/O for 7 series TX clock lane and restrict the I/O selection within the I/O bank for MIPI D-PHY TX.

It is recommended to select the I/O bank with VRP pin connected for UltraScale+ MIPI D-PHY TX IP core. If VRP pin is present in other I/O bank in the same I/O column of the device the following DCI\_CASCADE XDC constraint should be used. For example, I/O bank 65 has a VPR pin and the D-PHY TX IP is using the I/O bank 66.

```
set_property DCI_CASCADE {66} [get_iobanks 65]
```

## Simulation

For comprehensive information about Vivado simulation components, as well as information about using supported third-party tools, see the *Vivado Design Suite User Guide: Logic Simulation* (UG900) [\[Ref 11\]](#).

---

## Synthesis and Implementation

For details about synthesis and implementation, see the *Vivado Design Suite User Guide: Designing with IP* (UG896) [\[Ref 9\]](#).

# Verification, Compliance, and Interoperability

The MIPI CSI-2 TX Subsystem has been verified using both simulation and hardware testing. A highly parameterizable transaction-based simulation test suite has been used to verify the subsystem. The tests include:

- Different lane combinations and line rates
- High-Speed Data transmission with short/long packets, different virtual channels and different data types.
- All possible interleaving cases (data type and virtual channel)
- All possible output pixel, data type combinations.
- Register read and write access

---

## Hardware Validation

The MIPI CSI-2 TX Subsystem is tested in hardware for functionality, performance, and reliability using Xilinx® evaluation platforms. The MIPI CSI-2 TX Subsystem verification test suites for all possible modules are continuously being updated to increase test coverage across the range of possible parameters for each individual module.

A series of MIPI CSI-2 TX Subsystem test scenarios are validated using the Xilinx development boards listed in [Table A-1](#). These boards permit the prototyping of system designs where the MIPI CSI-2 TX Subsystem processes the incoming image data into different short/long packets.

**Table A-1: Xilinx Development Board**

Target Family	Evaluation Board	Characterization Board
Zynq® UltraScale+™ MPSoC	ZCU102	N/A

7 Series devices do not have a native MIPI IOB support. You will have to target the HP bank I/O for MIPI IP implementation. For more information on MIPI IOB compliant solution and guidance, refer *D-PHY Solutions* (XAPP894) [\[Ref 15\]](#).

# Debugging

This appendix includes details about resources available on the Xilinx Support website and debugging tools.

---

**TIP:** *If the IP generation halts with an error, there might be a license issue. See [License Checkers in Chapter 1](#) for more details.*

---

## Finding Help on Xilinx.com

To help in the design and debug process when using the MIPI CSI-2 Transmit Subsystem, the [Xilinx Support web page](#) contains key resources such as product documentation, release notes, answer records, information about known issues, and links for obtaining further product support.

### Documentation

This product guide is the main document associated with the MIPI CSI-2 Transmit Subsystem. This guide, along with documentation related to all products that aid in the design process, can be found on the [Xilinx Support web page](#) or by using the Xilinx Documentation Navigator.

Download the Xilinx Documentation Navigator from the [Downloads page](#). For more information about this tool and the features available, open the online help after installation.

### Answer Records

Answer Records include information about commonly encountered problems, helpful information on how to resolve these problems, and any known issues with a Xilinx product. Answer Records are created and maintained daily ensuring that users have access to the most accurate information available.

Answer Records for this subsystem can be located by using the Search Support box on the main [Xilinx support web page](#). To maximize your search results, use proper keywords such as:

- Product name
- Tool message(s)
- Summary of the issue encountered

A filter search is available after results are returned to further target the results.

### **Master Answer Record for the MIPI CSI-2 Transmit Subsystem**

AR: [67896](#)

## **Technical Support**

Xilinx provides technical support at the [Xilinx Support web page](#) for this IP product when used as described in the product documentation. Xilinx cannot guarantee timing, functionality, or support if you do any of the following:

- Implement the solution in devices that are not defined in the documentation.
- Customize the solution beyond that allowed in the product documentation.
- Change any section of the design labeled DO NOT MODIFY.

Xilinx provides premier technical support for customers encountering issues that require additional assistance.

To contact Xilinx Technical Support, navigate to the [Xilinx Support web page](#).

---

## **Debug Tools**

There are many tools available to address MIPI CSI-2 Transmit Subsystem design issues. It is important to know which tools are useful for debugging various situations.

### **Vivado Design Suite Debug Feature**

The Vivado® Design Suite debug feature inserts logic analyzer and virtual I/O cores directly into your design. The debug feature also allows you to set trigger conditions to capture application and integrated block port signals in hardware. Captured signals can then be analyzed. This feature in the Vivado IDE is used for logic debugging and validation of a design running in Xilinx devices.

The Vivado logic analyzer is used with the logic debug IP cores, including:

- ILA 2.0 (and later versions)
- VIO 2.0 (and later versions)

See the *Vivado Design Suite User Guide: Programming and Debugging* (UG908) [Ref 13].

---

## Hardware Debug

Hardware issues can range from link bring-up to problems seen after hours of testing. This section provides debug steps for common issues. The Vivado debug feature is a valuable resource to use in hardware debug. The signal names mentioned in the following individual sections can be probed using the debug feature for debugging the specific problems.

### General Checks

- Ensure MIPI DPHY and MIPI CSI-2 TX Controller cores are in the enable state by reading the registers.
- Ensure Incorrect Lane Configuration is not set in the MIPI CSI-2 TX Controller Interrupt status register.
- Ensure line buffer full condition is not set in the MIPI CSI-2 TX Controller Interrupt Status register.
- Ensure Pixel Data Under-run is not set in the MIPI CSI-2 TX Controller Interrupt Status register.
- Ensure GSP FIFO Full is not set in the MIPI CSI-2 TX Controller Interrupt Status register.

**Note:** In case, you encounter any errors, disable and re-enable the core to clear any stale data stored in the buffers.

---

## Interface Debug

### AXI4-Lite Interfaces

Read from a register that does not have all 0s as a default to verify that the interface is functional. See [Figure B-1](#) for a read timing diagram. Output `s_axi_arready` asserts when the read address is valid, and output `s_axi_rvalid` asserts when the read data/response is valid. If the interface is unresponsive, ensure that the following conditions are met:

- The `lite_aclk` inputs are connected and toggling.
- The interface is not being held in reset, and `lite_aresetn` is an active-Low reset.

- The main subsystem clocks are toggling and that the enables are also asserted.
- If the simulation has been run, verify in simulation and/or a debug feature capture that the waveform is correct for accessing the AXI4-Lite interface.




Figure B-1: AXI4-Lite Timing

## AXI4-Stream Interfaces

If data is not being transmitted or received, check the following conditions:

- If transmit `<interface_name>_tready` is stuck Low following the `<interface_name>_tvalid` input being asserted, the subsystem cannot send data.
- If the receive `<interface_name>_tvalid` is stuck Low, the subsystem is not receiving data.
- Check that the `s_axis_aclk` and `dphy_clk_200M` inputs are connected and toggling.
- Check subsystem configuration.
- Ensure “line buffer full” condition not getting reported in subsystem Interrupt Status register.





Figure B-2: AXI4-Stream Timing

## Native Interfaces

If data is not being transmitted or received, check the following conditions:

- If the receive <interface\_name>\_vid\_enable is stuck Low, the subsystem is not receiving data.
- Check that the s\_axis\_aclk and dphy\_clk\_200M inputs are connected and toggling.
- Check subsystem configuration.
- Ensure “line buffer full” condition not getting reported in subsystem Interrupt Status register.



*Figure B-3: Native Interface Timing*

# Additional Resources and Legal Notices

---

## Xilinx Resources

For support resources such as Answers, Documentation, Downloads, and Forums, see [Xilinx Support](#).

---

## References

These documents provide supplemental material useful with this product guide:

1. MIPI Alliance Standard for Camera Serial Interface CSI-2: [mipi.org/specifications/camera-interface#CSI2](http://mipi.org/specifications/camera-interface#CSI2)
2. *AXI4-Stream Video IP and System Design Guide* ([UG934](#))
3. *MIPI D-PHY LogiCORE IP Product Guide* ([PG202](#))
4. *AXI Interconnect LogiCORE IP Product Guide* ([PG059](#))
5. *AXI IIC Bus Interface v2.0 LogiCORE IP Product Guide* ([PG090](#))
6. MIPI Alliance Physical Layer Specifications, D-PHY Specification: <http://mipi.org/specifications/physical-layer#D-PHY Specification>
7. *Vivado Design Suite: AXI Reference Guide* ([UG1037](#))
8. *Vivado Design Suite User Guide: Designing IP Subsystems using IP Integrator* ([UG994](#))
9. *Vivado Design Suite User Guide: Designing with IP* ([UG896](#))
10. *Vivado Design Suite User Guide: Getting Started* ([UG910](#))
11. *Vivado Design Suite User Guide: Logic Simulation* ([UG900](#))
12. *ISE to Vivado Design Suite Migration Guide* ([UG911](#))
13. *Vivado Design Suite User Guide: Programming and Debugging* ([UG908](#))
14. *Vivado Design Suite User Guide: Implementation* ([UG904](#))
15. *D-PHY Solutions* ([XAPP894](#))

## Revision History

The following table shows the revision history for this document.

Date	Version	Revision
06/07/2017	1.0	Enhancement support for non-continuous clock mode
04/05/2017	1.0	<ul style="list-style-type: none"> <li>• MIPI D-PHY 3.1 changes integrated</li> <li>• Enhancement support for a case where the word count is greater than the payload received.</li> </ul>
10/05/2016	1.0	Initial Xilinx release

## Please Read: Important Legal Notices

The information disclosed to you hereunder (the "Materials") is provided solely for the selection and use of Xilinx products. To the maximum extent permitted by applicable law: (1) Materials are made available "AS IS" and with all faults, Xilinx hereby DISCLAIMS ALL WARRANTIES AND CONDITIONS, EXPRESS, IMPLIED, OR STATUTORY, INCLUDING BUT NOT LIMITED TO WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, OR FITNESS FOR ANY PARTICULAR PURPOSE; and (2) Xilinx shall not be liable (whether in contract or tort, including negligence, or under any other theory of liability) for any loss or damage of any kind or nature related to, arising under, or in connection with, the Materials (including your use of the Materials), including for any direct, indirect, special, incidental, or consequential loss or damage (including loss of data, profits, goodwill, or any type of loss or damage suffered as a result of any action brought by a third party) even if such damage or loss was reasonably foreseeable or Xilinx had been advised of the possibility of the same. Xilinx assumes no obligation to correct any errors contained in the Materials or to notify you of updates to the Materials or to product specifications. You may not reproduce, modify, distribute, or publicly display the Materials without prior written consent. Certain products are subject to the terms and conditions of Xilinx's limited warranty, please refer to Xilinx's Terms of Sale which can be viewed at <https://www.xilinx.com/legal.htm#tos>; IP cores may be subject to warranty and support terms contained in a license issued to you by Xilinx. Xilinx products are not designed or intended to be fail-safe or for use in any application requiring fail-safe performance; you assume sole risk and liability for use of Xilinx products in such critical applications, please refer to Xilinx's Terms of Sale which can be viewed at <https://www.xilinx.com/legal.htm#tos>.

### AUTOMOTIVE APPLICATIONS DISCLAIMER

AUTOMOTIVE PRODUCTS (IDENTIFIED AS "XA" IN THE PART NUMBER) ARE NOT WARRANTED FOR USE IN THE DEPLOYMENT OF AIRBAGS OR FOR USE IN APPLICATIONS THAT AFFECT CONTROL OF A VEHICLE ("SAFETY APPLICATION") UNLESS THERE IS A SAFETY CONCEPT OR REDUNDANCY FEATURE CONSISTENT WITH THE ISO 26262 AUTOMOTIVE SAFETY STANDARD ("SAFETY DESIGN"). CUSTOMER SHALL, PRIOR TO USING OR DISTRIBUTING ANY SYSTEMS THAT INCORPORATE PRODUCTS, THOROUGHLY TEST SUCH SYSTEMS FOR SAFETY PURPOSES. USE OF PRODUCTS IN A SAFETY APPLICATION WITHOUT A SAFETY DESIGN IS FULLY AT THE RISK OF CUSTOMER, SUBJECT ONLY TO APPLICABLE LAWS AND REGULATIONS GOVERNING LIMITATIONS ON PRODUCT LIABILITY.

© Copyright 2016-2017 Xilinx, Inc. Xilinx, the Xilinx logo, Artix, ISE, Kintex, Spartan, Virtex, Vivado, Zynq, and other designated brands included herein are trademarks of Xilinx in the United States and other countries. All other trademarks are the property of their respective owners.